



Young Regulator Co.

7100 Krick Rd • Walton Hills, OH 44146
 P: 440-232-9700 • F: 440-232-8266
www.youngregulator.com

Submit 3092 1-2019

Model 3092

*Electronic Bypass Damper Rectangular
 Pressure Reducing Damper*

Application and Design

The Young Regulator 3092 round bypass damper regulates the total airflow in the system by diverting the excess airflow through a ducted return or ceiling plenum.

An increase in static pressure is sensed by the built in static pressure sensor/controller through the probe. At the desired static pressure, (adjustable by the installer) the motor will begin to modulate the damper open to bypass the excess air flow, reducing static pressure. The damper will open until the desired static pressure is attained. Damper blade will stall and pressure will be maintained until another change in pressure. If zones are satisfied and more zone dampers close, bypass damper will open further. If zones require more air and zone dampers open, pressure reducing damper sensor will sense a decrease in pressure and the bypass damper will close.

The system can also be used to reduce downstream static by limiting the amount of air going into a branch. In that case the controller signals an "Open" on drop in static and a close on Pressure rise.



Standard Construction	
Bypass assembly of damper, actuator and static pressure sensor are prewired at the factory for a reliable, economical means of controlling pressure in a pressure dependent VAV system.	
Frame/Blades	14 ga. Roll Formed Galvanized Steel / 16 ga. Galvanized
Shaft / Bearings	½" Plated Steel / Oil Impregnated Bronze
Seals	Low-Leak Rubber Blade Seals & Stainless Steel Spring Jam Seals
Mounting Plate	5" wide x Damper Height
Sizes	8x8 to 48x48

Static Pressure Sensor/Controller	
Solid-Sate design with built-in LEDs to indicate damper operation and a 15 second delay to protect the motor and static pressure switch from short cycling on the close.	
Differential Pressure Setpoint Range	0.17 to 2.0 InWC
Operating Range	35° to 140° F
Electrical Switch	Floating Point, Single Pole Double Throw with Integral Arc Suppression Rates 1Amp @ 24VAC
Compliance / Enclosure	UL Listed / Nema 1
Actuator	
Brushless 24VAC Motor Power Open/Power Closed	
Volts / Watts / VA	24VAC / 1.5W running(0.2 W holding) / 2VA
Timing / Torque	35 Seconds / 45 in-lbs
Built-in motor stops for minimum and maximum air	

Quantity	Diameter	Bypass or Pressure Reduction	Notes
PROJECT			LOCATION
CONTRACTOR			DESIGN SPECIFIER



Young Regulator Co.

7100 Krick Rd • Walton Hills, OH 44146

P: 440-232-9700 • F: 440-232-8266

www.youngregulator.com

Model 3092 Electronic Bypass Damper

GENERAL INSTRUCTIONS FOR BYPASS DAMPER ASSEMBLY

HOW THE BYPASS SYSTEM WORKS

As the individual zone dampers open and close, the system static pressure will rise and fall. In order to maintain proper air flow and static pressure through the HVAC system, a bypass system incorporating a reversible type motorized damper and a static pressure control is used. The static pressure control is equipped with solid state switching and time delay to enhance its operation and improve its reliability.

INSTALLING THE BYPASS DAMPER AND STATIC PRESSURE CONTROL ASSEMBLY

The bypass damper should be installed with the bypass air being discharged into the return air plenum or above the ceiling if this area is used as a common return (see drawing). The bypass damper must be installed so that the diaphragm of the static pressure control is in the vertical position. The high-pressure side of the static pressure control should be connected to the sensing tube and inserted in the main supply plenum, downstream of the bypass damper and at least 2 to 3 feet from the air handling unit in a straight section of duct at the center line. The sensing tube furnished is a 7" (18cm) length of 1/4" (6mm) O.D. rigid tubing to be connected to the pressure control with 3/8" O.D. plastic tubing, inserted and sealed 6" (15cm) into the duct. The sensing tube, plastic tubing, and mounting fittings are furnished with damper assembly.

ADJUSTING THE STATIC PRESSURE CONTROL

Before adjusting the pressure control, the installer should confirm the following:

1. that the HVAC system has been properly balanced.
2. that all zone dampers are in the open position.

HOW TO PROCEED

With the air handler running and the bypass damper system powered, turn the static pressure adjusting screw clockwise until the bypass damper just starts to open (green light on) then turn the adjusting screw counter clockwise just enough so that the green light goes out and the damper is fully closed.

SPECIFICATIONS FOR BYPASS DAMPERS

- Pressure Set Point Range: .17" to 3" (4.3 to 76.2mm) InWC.
- Sensing Element: Neoprene diaphragm
- Electrical Connections: Two field connections.
- Pressure Connections: Barbed for 3/8" O.D. plastic tubing.
- Case: All metal with 1/2" conduit opening.
- Mounting: Damper to be installed with controller diaphragm in a vertical position.

Note:

Note:

Bypass damper must be installed so that the diaphragm of the static pressure control is always in the vertical position.

This Drawing of a bypass system is intended to serve only as a guide. Your actual duct work layout may differ substantially.

BYPASS DAMPER AND STATIC PRESSURE CONTROL ASSEMBLY

